


# Typical Splitter Kit Configuration (Model SRAS-2 Two-way amplified splitter shown)

## Included in the Kit:

- SMB to F input adapter (1)
- Matching Transformer (2)
- 3 ft F- plug to SMB plug cable (2)
- Splitter

Cable Length	Required Amps
0-25 ft	No amp req
26 -125 ft	1 line amp
126 - 250 ft	2 line amps
251 - 375 ft	3 line amps



### \* Important Notes:

1. For cable lengths on output of splitter exceeding 25 feet, use additional line amps as shown in Table 2. Amplifiers should be located at output of splitter.
2. For cable lengths on input of splitter exceeding 25 feet use additional line amps per Table 2. Amplifiers should be located at the output of the antenna's 20 ft cable.