


## Windows 7 XM Direct Device manager software upgrade


- 1) Browse to the Control Panel and click Hardware and Sound




- 2) Inside the Hardware and Sound click Device Manager (Most systems require you to be administrator in order to make modifications)




- 3) After opening up the device manager locate the Bad installation. The bad installation will show a Yellow and Black EXCLAMATION point.
- 4) **Right Click** on the Unknown Device and select **UPDATE DRIVER SOFTWARE**




- 5) Click the **BROWSE My Computer for Driver software**:




- 6) Verify the path is pointing to the driver installation files. (C:\Program Files\XM Direct 2 is the default location. If you cannot locate the files you must rerun the XM\_Direct\_2.msi file from <http://audiovox.com/xmdirect/>)




- 7) Windows will not know who the drivers are from so they give you a warning screen that you must accept and allow the install. Click **Install this driver software anyway** to continue.



8) Software is installing



9) Install is done



10) Verify in the device manager the device is reading as **XM Universal board V3**

